


TROUBLESHOOTING

FREQUENCY INTERFERENCE

If the fireplace does not respond properly to the remote control, the remote operating frequency may have to be reset. The remote control can send another frequency code to the circuit board to eliminate interference.

1. Simultaneously press the “**SLOW START**” button and the “**PURIFIRE LOW SPEED**” button on the remote control.
 2. “**CODE**” will appear.
 3. Release the “**SLOW START**” button and the “**PURIFIRE LOW SPEED**” button.
 4. Press and hold the initialization button on the unit.
 5. Press the  button on the remote and release the initialization button.
- Your remote will now have a different frequency communicating with the fireplace.