



## **INITIALIZATION / INSTALLATION**

### **REMOTE RECIEVER INSTALLATION**

1. Plug the remote receiver into the wall outlet.
2. Plug the fireplace into the outlet located on the side of the remote receiver.
3. Remove the battery cover and remove the plastic wrapping from the battery or pull to remove the battery insulator tab located on the back of the hand held transmitter.

### **WARNING**

To prevent the risk of fire, the fireplace plug must be inserted fully into the remote receiver.

Avoid the use of an extension cord. Extension cords may overheat and cause a risk of fire. If you must use an extension cord, the cord must be No. 16 AWG minimum size and rated no less than 1875 watts.